ZD410/ZD411/ZD420/ZD421 Manually Set Printer Width

1. Printer must be on;
2. Press **Pause Button** for 2 seconds until all lights briefly flash orange
3. Status light solid yellow;
4. Press **Feed Button** once, now Pause light lit
5. Press **Pause Button** once
6. Prints a box and pauses, prints a slightly larger box and pauses
7. When the box prints the correct size; press Feed Button to set width.